

Teldio TruFleet | MOTOTRBO Control Station for Voice Channels

- **General / General Settings**
 - Set an ID.
 - This same ID MUST be used for all Control stations used within a TruFleet deployment
 - Set High Power to 5 Watts. If it's a High Power Radio. Set High Power to 20 Watts.
 - Low Powered Mobiles are highly recommended.
 - Under Alerts/ Enable 'Disable All Tones'
- **General / Accessories**
 - Make sure Cable Type is 'Motorola Solutions'
- **General / Network**
 - Set the Radio IP to 192.168.100.1 (Each additional base station must have a different subnet – 192.168.101.1 / 192.168.102.1 and so on.)
 - Set USB DNS-SD Interval to Disabled
 - Set Forward to PC to Via USB
- **Zone/Channel**
 - There must only be one channel per Mobile Radio. This channel should be the first channel on the first zone in the Mobile radio and must be a voice channel.
 - **Conventional Modes:** Set up a channel with the information of the Radio Channel on which the ARS messages are received.
 - **Trunked Modes:** Set up one channel to listen to all repeaters via Voice List.
 - Remove RX Group List and TX Contact.
 - **If Motorola Emergencies are being tracked**, set up the channel to receive on the Motorola Emergency contact and the Motorola Emergency system.
 - Set Power to High
 - Set the TX Settings as shown below.

The screenshot shows the 'TX Settings' configuration window. It includes the following options and values:

- Allow Interruption:** ☒
- TX Interruptible Frequencies:** ☒
- Admit Criteria:** Color Code Free (dropdown menu)
- In Call Criteria:** Follow Admit Criteria (dropdown menu)
- RSSI Threshold (dBm):** -124 (spin box)
- GNSS Revert:** Selected (dropdown menu)
- Private Call Confirmed:** ☐
- Data Call Confirmed:** ☐

Teldio TruFleet | MOTOTRBO Control Station for Data Channels

- **General / General Settings**
 - Set an ID.
 - This same ID MUST be used for all Control stations used within a TruFleet deployment
 - Set High Power to 5 Watts. If it's a High Power Radio. Set High Power to 20 Watts.
 - Low Powered Mobiles are highly recommended.
 - Under Alerts/ Enable 'Disable All Tones'
- **General / Accessories**
 - Make sure Cable Type is 'Motorola Solutions'
- **General / Network**
 - Set the Radio IP to 192.168.101.1 (Each additional base station must have a different subnet – 192.168.102.1 / 192.168.103.1 and so on.)
 - Set USB DNS-SD Interval to Disabled
 - Set Forward to PC to Via USB
- **Zone/Channel**
 - There must only be one channel per Mobile Radio. This channel should be the first channel on the first zone in the Mobile radio and must be a data channel.
 - Set up a channel with the information of the Radio Channel on which the GPS Data is being received.
 - If using Enhanced GPS, enable the Enhanced GPS checkbox.
 - Set channel to RX Only.

Teldio TruFleet | Users being tracked via TruFleet

- **General / General Settings**
 - Ensure that GNSS is enabled
 - Ensure that Persistent LRRP Requests are disabled
- **General / Network / Services**
 - Set the ARS Radio ID and the TMS Radio ID to the ID allocated for the Control Stations or the MNIS instance.
- **If using Indoor Tracking: General / Indoor Tracking**
 - Enable Indoor Location checkbox
 - Beacon List:
 - If using Minew Beacons add the following:
 - Beacon Alias: Minew
 - Beacon UUID: E2C56DB5DFFB48D2B060D0F5A71096E0
 - If using Loc-Ex Beacons add the following:
 - Beacon Alias: LOCEX
 - Beacon UUID: 2673DAF8E45E4D85A91D6DF91D9BCD79
- **Zone / Channel**
 - Voice Channels
 - Enable ARS
 - If using TruFleet's Sprite Firmware, enable Option Board
 - Trunked Systems: Associate the Proper Voice and Data Lists
 - Conventional Systems: Set the GPS Data Revert Zone and Channel
 - Set Location Delivery mode to 'unconfirmed'
 - Data Channels (Conventional Systems)
 - These channels should be set up in the Channel Pool
 - Do not enable ARS
 - If Enhanced GPS is set up in the system, enable Enhanced GPS checkbox
 - If using TruFleet's Sprite Firmware, enable Option Board
 - Ensure there are no RX Groups or TX Contacts
 - Set Location Delivery mode to 'unconfirmed'
 - Data Channels (Trunked Systems)
 - These channels should be set up in the Channel Pool
 - If Enhanced GPS is set up in the system, enable Enhanced GPS checkbox
 - If Enhanced GPS is set up in the system, on the Capacity Plus Data Lists, set Enhanced GNSS window size to below
 - GPS only: 8
 - GPS and Indoor Tracking: 10